
100
102
110
108
106
104

FIG. 1


208
204
202
216
PROCESSOR
HOST/PCI CACHE/BRIDGE
MAIN MEMORY
AUDIO ADAPTER
206
BUS
212
210
214
218
219
SCSI HOST BUS ADAPTER
LAN ADAPTER
EXPANSION BUS INTERFACE
GRAPHICS ADAPTER
AUDIO/VIDEO ADAPTER
226
DISK
228
TAPE
230
CD-ROM
232
KEYBOARD AND MOUSE ADAPTER
MODEM
MEMORY
220
222
224
200
CLIENT

FIG. 2


300
301
BOOK FLIGHT
HELP
302
310
303
320
FROM
TO
304
LEAVING AT
330

FIG. 3A


300
301
311
BOOK FLIGHT
HELP
302
ATLANTA
CHICAGO
DALLAS
DENVER
303
320
FROM
TO
304
310
LEAVING AT
330

FIG. 3B


300
301
BOOK FLIGHT
HELP
302
310
303
320
FROM
ATLANTA
TO
CHICAGO
304
LEAVING AT
10:00 A.M.
330
AND
305

FIG. 3C


300
301
BOOK FLIGHT
HELP
302
310
303
320
FROM
ATLANTA
TO
CHICAGO
304
LEAVING AT
10:00 A.M.
330
305
AND
FROM
CHICAGO
TO
DENVER
LEAVING AT
7:00 P.M.
340
AND

FIG. 3D


300
301
BOOK FLIGHT
HELP
302
310
303
320
FROM
ATLANTA
TO
CHICAGO
304
LEAVING AT
10:00 A.M.
330
SPECIAL REQUEST
307
306

FIG. 3E


300
301
BOOK FLIGHT
HELP
302
310
303
320
FROM
TO
SPECIAL REQUEST
HELP
351
MEAL CHOICE
VEGETARIAN
350
SEAT BY
ISLE
WINDOW
SKIP
352

FIG. 3F


MACHINE
HUMAN
PUSH AND RELEASE TALK BUTTON.
"BOOK FLIGHT FROM BOSTON TO DENVER LEAVING ONE P.M."

FIG. 4


VOICE-ONLY DIALOG
MACHINE
HUMAN
START TO SPEAK TONE.
"BOOK FLIGHT FROM."
END SPEAK TONE.
PRESS AND RELEASE TALK BUTTON.
"BOSTON"
START TO SPEAK TONE.
"TO"
END SPEAK TONE.
PRESS AND RELEASE TALK BUTTON.
"CHICAGO"
START TO SPEAK TONE.
"LEAVING"
END SPEAK TONE.
PRESS AND RELEASE TALK BUTTON.
"ONE P.M."
501

FIG. 5


VOICE-ONLY DIALOG
MACHINE
HUMAN
START TO SPEAK TONE.
"BOOK FLIGHT FROM."
END SPEAK TONE.
PRESS AND RELEASE TALK BUTTON.
"WHAT?"
601
START TO SPEAK TONE.
"CITY"
END SPEAK TONE.
PRESS AND RELEASE TALK BUTTON.
"BOSTON"

FIG. 6


VOICE-ONLY DIALOG
MACHINE
HUMAN
START TO SPEAK TONE.
"BOOK FLIGHT FROM"
END SPEAK TONE.
PRESS AND RELEASE TALK BUTTON.
"LIST."
701
START TO SPEAK TONE.
"ATLANTA,CHICAGO,DALLAS,OR DENVER"
END SPEAK TONE.
702
PRESS AND RELEASE TALK BUTTON.
"CHICAGO"

FIG. 7